

# nüvi® 3507/3508 Series Owner's Manual



All rights reserved. Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of Garmin. Garmin reserves the right to change or improve its products and to make changes in the content of this manual without obligation to notify any person or organization of such changes or improvements. Go to [www.garmin.com](http://www.garmin.com) for current updates and supplemental information concerning the use of this product.

Garmin®, nüvi®, and the Garmin logo are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. These trademarks may not be used without the express permission of Garmin.

BaseCamp™, HomePort™, MapSource®, myGarmin™, ecoRoute™, myTrends™, trafficTrends™, nüMaps Guarantee™, and nüMaps Lifetime™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc., and any use of such name by Garmin is under license. microSD™ and the microSDHC logo are trademarks of SD-3C, LLC. Windows®, Windows Vista®, and Windows XP® are registered trademarks of Microsoft Corporation in the United States and other countries. Mac® is a trademark of Apple Inc. HD Radio™ and the HD logo are trademarks of iBiquity Digital Corporation. HD Radio Technology manufactured under license from iBiquity Digital Corporation. U.S. and foreign patents.

# Table of Contents

<b>Getting Started</b> .....	<b>1</b>
Connecting the Device to Vehicle Power.....	1
Support and Updates.....	1
Setting Up Garmin Express.....	1
nüMaps Guarantee™.....	1
Lifetime Subscriptions.....	1
Entering and Exiting Sleep Mode.....	1
Turning Off the Device.....	1
Resetting the Device.....	1
Acquiring GPS Signals.....	1
Adjusting the Screen Brightness.....	2
Adjusting the Volume.....	2
About Automatic Volume.....	2
Status Bar Icons.....	2
Viewing GPS Signal Status.....	2
Battery Information.....	2
Setting the Time.....	2
Using the On-Screen Buttons.....	2
Using the On-Screen Keyboard.....	2
<b>Locations</b> .....	<b>2</b>
Finding Locations.....	2
Finding a Location by Category.....	2
Finding a Location Using the Search Bar.....	2
Changing the Search Area.....	3
Finding a Location by Browsing the Map.....	3
Finding an Address.....	3
Finding Recently Found Destinations.....	3
Finding Parking.....	3
Search Tools.....	3
Saving Locations.....	3
Saving a Location.....	3
Saving Your Current Location.....	3
Saving a Home Location.....	3
Editing a Saved Location.....	3
Assigning Categories to a Saved Location.....	4
Deleting a Saved Location.....	4
Setting a Simulated Location.....	4
Adding a Shortcut.....	4
Removing a Shortcut.....	4
Custom Points of Interest.....	4
Installing POI Loader.....	4
Using the POI Loader Help Files.....	4
Finding Custom POIs.....	4
<b>Navigation</b> .....	<b>4</b>
Starting a Route.....	4
Previewing Multiple Routes.....	4
Changing the Route Calculation Mode.....	4
Starting a Route to a Saved Location.....	4
Your Route on the Map.....	4
Using the Navigation Map.....	5
Adding a Point to a Route.....	5
Taking a Detour.....	5
Stopping the Route.....	5
Viewing Route Activity.....	5
Viewing a List of Turns.....	5
Viewing the Next Turn.....	5
Viewing Junctions.....	5
About Up Ahead.....	5
Finding Upcoming Points of Interest.....	5
Customizing the Up Ahead Categories.....	5
Trip Information.....	5
Viewing Trip Data from the Map.....	5
Viewing the Trip Information Page.....	6

Viewing the Trip Log.....	6
Resetting Trip Information.....	6
Using Suggested Routes.....	6
Viewing Current Location Information.....	6
Finding Nearby Services.....	6
Getting Directions to Your Current Location.....	6
Avoiding Road Features.....	6
About Custom Avoidances.....	6
Avoiding an Area.....	6
Avoiding a Road.....	6
Disabling a Custom Avoidance.....	6
Deleting Custom Avoidances.....	6
Customizing the Map.....	6
Customizing the Map Tools.....	6
Customizing the Map Layers.....	6
Changing the Map Data Field.....	7
Changing the Map Perspective.....	7
Safety Cameras.....	7
<b>Traffic</b> .....	<b>7</b>
Receiving Traffic Data Using a Traffic Receiver.....	7
Traffic Receiver.....	7
Positioning the Traffic Receiver.....	7
Viewing Upcoming Traffic.....	7
Viewing Traffic on the Map.....	7
Searching for Traffic Incidents.....	8
Traffic on Your Route.....	8
Taking an Alternate Route.....	8
About Traffic Cameras.....	8
Saving a Traffic Camera.....	8
Viewing a Traffic Camera.....	8
About Traffic Subscriptions.....	8
Subscription Activation.....	8
Viewing Traffic Subscriptions.....	8
Adding a Subscription.....	8
trafficTrends™.....	8
Disabling trafficTrends.....	8
Enabling Traffic.....	8
<b>Voice Command</b> .....	<b>8</b>
Setting the Wakeup Phrase.....	8
Activating Voice Command.....	8
Voice Command Tips.....	8
Starting a Route Using Voice Command.....	9
Muting Instructions.....	9
Disabling Voice Command.....	9
<b>Hands-Free Phone Calls</b> .....	<b>9</b>
About Hands-Free Calling.....	9
Enabling Bluetooth Wireless Technology.....	9
Pairing Your Phone.....	9
Tips After Pairing the Devices.....	9
Disconnecting Your Phone.....	9
Deleting a Paired Phone.....	9
Placing a Call.....	9
Dialing a Number.....	9
Calling a Contact in Your Phone Book.....	9
Calling a Location.....	9
Receiving a Call.....	9
Using the Call History.....	9
Using In-Call Options.....	9
Saving a Home Phone Number.....	10
Calling Home.....	10
<b>Using the Apps</b> .....	<b>10</b>
Using Help.....	10
Searching Help Topics.....	10
Smartphone Link.....	10
Downloading Smartphone Link.....	10

Connecting to Smartphone Link.....	10	My battery does not stay charged for very long.....	15
Sending a Location from Your Phone to Your Device.....	10	The battery gauge does not seem accurate.....	15
Disabling Calls While Connected to Smartphone Link.....	10	My device does not appear as a removable drive on my	
Garmin Live Services.....	10	computer.....	15
Subscribing to Garmin Live Services.....	10	My device does not appear as a portable device on my	
About ecoRoute.....	10	computer.....	15
ecoRoute HD Accessory.....	10	My device does not appear as either a portable device or a	
Setting Up the Vehicle.....	11	removable drive or volume on my computer.....	15
Changing the Fuel Price.....	11	My phone will not connect to the device.....	15
Calibrating the Fuel Economy.....	11	<b>Index.....</b>	<b>16</b>
About ecoChallenge.....	11		
Viewing Fuel Economy Information.....	11		
Mileage Reports.....	11		
Resetting ecoRoute Information.....	11		
Viewing myGarmin Messages.....	11		
Viewing the Weather Forecast.....	11		
Viewing Weather Near a Different City.....	11		
Viewing the Weather Radar.....	11		
Viewing Weather Alerts.....	11		
Checking Road Conditions.....	11		
Planning a Trip.....	11		
Scheduling a Trip.....	12		
Navigating to a Saved Trip.....	12		
Editing a Saved Trip.....	12		
Viewing Previous Routes and Destinations.....	12		
<b>Data Management.....</b>	<b>12</b>		
File Types.....	12		
About Memory Cards.....	12		
Installing a Memory Card.....	12		
Connecting the Device to Your Computer.....	12		
Transferring Data From Your Computer.....	12		
Disconnecting the USB Cable.....	12		
<b>Customizing the Device.....</b>	<b>12</b>		
Map and Vehicle Settings.....	12		
Enabling Maps.....	13		
Navigation Settings.....	13		
Route Preferences.....	13		
Display Settings.....	13		
Bluetooth Settings.....	13		
Disabling Bluetooth.....	13		
Traffic Settings.....	13		
Units and Time Settings.....	13		
Language and Keyboard Settings.....	13		
Device and Privacy Settings.....	13		
Proximity Alerts Settings.....	13		
Restoring Settings.....	13		
<b>Appendix.....</b>	<b>14</b>		
Power Cables.....	14		
Charging the Device.....	14		
Changing the Fuse in the Vehicle Power Cable.....	14		
Device Care.....	14		
Cleaning the Outer Casing.....	14		
Cleaning the Touchscreen.....	14		
Avoiding Theft.....	14		
Mounting on Your Dashboard.....	14		
Removing the Device, Mount, and Suction Cup.....	14		
Removing the Device from the Mount.....	14		
Removing the Mount from the Suction Cup.....	14		
Removing the Suction Cup from the Windshield.....	14		
Purchasing Additional Maps.....	14		
Purchasing Accessories.....	14		
<b>Troubleshooting.....</b>	<b>14</b>		
The suction cup will not stay on my windshield.....	14		
My device is not acquiring satellite signals.....	15		
The device does not charge in my vehicle.....	15		

## Getting Started

### ⚠ WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

## Connecting the Device to Vehicle Power

### ⚠ WARNING

This product contains a lithium-ion battery. To prevent the possibility of personal injury or product damage caused by battery exposure to extreme heat, store the device out of direct sunlight.

Both the device and its mount contain magnets. Under certain circumstances, magnets may cause interference with some internal medical devices, including pacemakers and insulin pumps. Keep the device and its mount away from such medical devices.

### NOTICE

Both the device and its mount contain magnets. Under certain circumstances, magnets may cause damage to some electronic devices, including hard drives in laptop computers. Use caution when the device or its mount is near electronic devices.

Before you use your device on battery power, you should charge it.

- 1 Plug the vehicle power cable ① into the USB port on the mount.



- 2 Press the mount ② onto the suction cup ③ until it snaps into place.  
The Garmin® logo on the mount should face right-side up.
- 3 Press the suction cup to the windshield, and flip the lever ④ back toward the windshield.
- 4 Place the back of the device onto the magnetic mount.
- 5 Plug the other end of the vehicle power cable into a power outlet in your vehicle.

## Support and Updates

Garmin Express provides easy access to these services for your device.

- Product registration
- Software and map updates
- Product manuals
- Vehicles, voices, and other extras

## Setting Up Garmin Express

- 1 Plug the small end of the USB cable into the port on the device.
- 2 Plug the larger end of the USB cable into an available USB port on your computer.
- 3 Go to [www.garmin.com/express](http://www.garmin.com/express).
- 4 Follow the on-screen instructions.

## nüMaps Guarantee™

Your device may be eligible for a free map update within 90 days of first acquiring satellites while driving. Go to [www.garmin.com/numaps](http://www.garmin.com/numaps) for terms and conditions.

## Lifetime Subscriptions

Some models include subscriptions to lifetime features. For more information, go to [www.garmin.com/lmt](http://www.garmin.com/lmt).

**LT:** This model includes a lifetime traffic subscription and a traffic receiver.

**LM:** This model includes a nüMaps Lifetime™ subscription, which provides quarterly map updates for the useful life of your device. For terms and conditions go to [www.garmin.com/us/maps/numaps\\_lifetime](http://www.garmin.com/us/maps/numaps_lifetime).

**LMT:** This model includes a nüMaps Lifetime subscription, lifetime traffic subscription, and a traffic receiver.

**LMTD or LMT-D:** This model includes a nüMaps Lifetime subscription, lifetime digital traffic subscription, and a digital traffic receiver.

## Activating Lifetime Maps

- 1 Go to [www.garmin.com/express](http://www.garmin.com/express).
- 2 Follow the on-screen instructions.

**NOTE:** If you register the device, you can receive e-mail notifications when a map update is available.

## Entering and Exiting Sleep Mode

You can use sleep mode to conserve battery power when your device is not in use. While in sleep mode, your device uses very little power and can wake instantly for use.

**TIP:** You can save power by putting the device in sleep mode while charging the battery.

Press the power key ①.



## Turning Off the Device


- 1 Hold the power key until a prompt appears on the screen.  
The prompt appears after five seconds. If you release the power key before the prompt appears, the device enters sleep mode.
- 2 Select **Off**.


## Resetting the Device

You can reset your device if it stops functioning.

Hold the power key for 10 seconds.

## Acquiring GPS Signals



To navigate with your device, you must acquire satellites.  in the status bar indicates the satellite signal strength (see [page 2](#)). Acquiring satellites can take several minutes.

- 1 Turn on the device.
- 2 If necessary, go outdoors to an open area, away from tall buildings and trees.
- 3 If necessary, hold  to view detailed information about the satellite signals.

## Adjusting the Screen Brightness

- 1 Select **Settings > Display > Brightness**.
- 2 Use the slider bar to adjust the brightness.

## Adjusting the Volume

- 1 Select **Volume**.
- 2 Select an option:
  - Use the slider bar to adjust the volume.
  - Select  to mute the device.
  - Select  for additional options.


### About Automatic Volume

On devices with hands-free calling, automatic volume allows the device to adjust the volume level based on the background noise in the vehicle (page 9).

Automatic volume control lowers the volume of the device when background noise is low and raises the volume level when background noise increases.





### Enabling Automatic Volume

Your device can increase or decrease the volume automatically based on the level of background noise.


- 1 Select **Volume > **.
- 2 If necessary, select **Automatic Volume**.
- 3 Select **Enabled**.

## Status Bar Icons

The status bar is located at the top of the main menu. The status bar icons display information about features on the device. You can select some icons to change settings or view additional information.


	GPS signal status
	Bluetooth® technology status (appears when Bluetooth is enabled)
<b>9:10<sup>A</sup></b>	Current time
	Battery status
	Connected to Smartphone Link
<b>53°<sup>F</sup></b>	Temperature

### Viewing GPS Signal Status

Hold  for three seconds.

### Battery Information

After the device is connected to power, it begins to charge.








 in the status bar indicates the status of the internal battery. To increase the accuracy of the battery gauge, you should fully discharge the battery and then fully charge it. Do not unplug the device until it is fully charged.

### Setting the Time

**NOTE:** You can select **Automatic** to automatically set the time each time the device is powered on.






- 1 Select **9:10<sup>A</sup>**.
- 2 Scroll the numbers to set the time.

## Using the On-Screen Buttons

- Select  to return to the previous menu screen.
- Hold  to quickly return to the main menu.
- Select  or  to see more choices.
- Hold  or  to scroll faster.
- Select  to see a menu of options for the current screen.

## Using the On-Screen Keyboard

See "Language and Keyboard Settings" to change the keyboard layout (page 13).

- Select  to delete a search entry.
- Select  to delete a character.
- Select  to change the keyboard language mode.
- Select  to enter special characters, such as punctuation marks.
- Select  to change character capitalization.

## Locations

The detailed maps loaded in your device contain locations, such as restaurants, hotels, auto services, and detailed street information. You can use categories to browse for nearby businesses and attractions. You can also search for addresses, coordinates, cities, and intersections.

## Finding Locations


### Finding a Location by Category

- 1 Select **Where To?**.
- 2 Select a category, or select **Categories**.
- 3 If necessary, select a subcategory.
- 4 Select a location.

### Searching Within a Category

After you have performed a search for a point of interest, certain categories may display a Quick Search list that shows the last three destinations you selected.

- 1 Select **Where To?**.
- 2 Select a category, or select **Categories**.
- 3 Select a category.
- 4 If applicable, select a destination from the Quick Search list.



- 5 If necessary, select the appropriate destination.

### Finding a Location Using the Search Bar

You can use the search bar to search for locations by entering a category, brand name, address, or city name.

- 1 Select **Where To?**.
- 2 Select **Enter Search** in the search bar.
- 3 Enter all or part of the search term.  
Suggested search terms appear below the search bar.
- 4 Select an option:
  - To search for a type of business, enter a category name (for example, "movie theaters").
  - To search for a business name, enter all or part of the name.
  - To search for an address near you, enter the street number and street name.
  - To search for an address in another city, enter the street number, street name, city, and state.
  - To search for a city, enter the city and state.

- To search for coordinates, enter latitude and longitude coordinates.

5 Select an option:

- To search using a suggested search term, select the term.
- To search using the text you entered, select **Q**.

6 If necessary, select a location.

### Changing the Search Area

1 From the main menu, select **Where To?**.

2 Select **Searching Near**.

3 Select an option.

### Finding a Location by Browsing the Map

Before you can find places included in the map data, such as restaurants, hospitals, and fuel stations, you must enable the map layer for places along the road ([page 6](#)).

1 Select **View Map**.

2 Drag and zoom the map to display the area to search.

3 If necessary, select **Q**, and select a category icon to view only a specific category of places.

Location markers (📍 or a blue dot) appear on the map.

4 Select an option:

- Select a location marker.
- Select a point, such as a street, intersection, or address location.

5 If necessary, select the location description to view additional information.

### Finding an Address

**NOTE:** The order of the steps may change depending on the map data loaded on your device.

1 Select **Where To? > Address**.

2 Enter the address number, and select **Done**.

3 Enter the street name, and select **Next**.

4 If necessary, select **Searching Near** to change the city, state, or province.

5 If necessary, select the city, the state, or the province.

6 If necessary, select the address.

### Finding Recently Found Destinations

Your device stores the last 50 destinations you have found.

1 Select **Where To? > Recent**.

2 Select a location.

### Clearing the List of Recently Found Locations

Select **Where To? > Recent > ☰ > Clear > Yes**.

### Finding Parking

1 Select **Where To? > Categories > Parking**.

2 Select a parking location.

### Finding Your Last Parking Spot

When you disconnect the device from vehicle power while the device is on, your current location is saved as a parking spot.

Select **Apps > Last Spot**.

### Search Tools

Search tools allow you to search for specific types of locations by responding to on-screen prompts.

#### Finding an Intersection

1 Select **Where To? > Categories > Intersections**.

2 Select an option:

- Select a state or province.

- To change the country, state, or province, select **State or Country**, and enter a name.

3 Enter the first street name, and select **Next**.

4 If necessary, select the street.

5 Enter the second street name, and select **Next**.

6 If necessary, select the street.

7 If necessary, select the intersection.

#### Finding a City

1 Select **Where To? > Categories > Cities**.

2 Select **Enter Search**.

3 Enter a city name, and select **Q**.

4 Select a city.

#### Finding a Location Using Coordinates

You can find a location using latitude and longitude coordinates. This can be helpful when geocaching.

1 Select **Where To? > Categories > Coordinates**.

2 If necessary, select **↵**, and change the coordinate format or datum.

3 Select the latitude coordinate.

4 Enter the new coordinate, and select **Done**.

5 Select the longitude coordinate.

6 Enter the new coordinate, and select **Done**.

7 Select **View on Map**.

## Saving Locations

### Saving a Location

1 Search for a location ([page 2](#)).

2 From the search results, select a location.

3 Select **i**.

4 Select **☰ > Save**.

5 If necessary, enter a name, and select **Done**.

### Saving Your Current Location

1 From the map, select the vehicle icon.

2 Select **Save**.

3 Enter a name, and select **Done**.

4 Select **OK**.

### Saving a Home Location

You can set your home location for the location you return to most often.

1 Select **Where To? > ☰ > Set Home Location**.

2 Select **Enter My Address, Use Current Location, or Recently Found**.

The location is saved as "Home" in the Saved menu.

### Going Home

Select **Where To? > Go Home**.

### Editing Your Home Location Information

1 Select **Where To? > Saved > Home**.

2 Select **i**.

3 Select **☰ > Edit**.

4 Enter your changes.

5 Select **Done**.

### Editing a Saved Location

1 Select **Where To? > Saved**.

2 If necessary, select a category.

3 Select a location.

- 4 Select **i**.
- 5 Select **≡** > **Edit**.
- 6 Select an option:
  - Select **Name**.
  - Select **Phone Number**.
  - Select **Categories** to assign categories to the saved location.
  - Select **Change Map Symbol** to change the symbol used to mark the saved location on a map.
- 7 Edit the information.
- 8 Select **Done**.

### Assigning Categories to a Saved Location

You can add custom categories to organize your saved locations.

**NOTE:** Categories appear in the saved locations menu after you have saved at least 12 locations.

- 1 Select **Where To?** > **Saved**.
- 2 Select a location.
- 3 Select **i**.
- 4 Select **≡** > **Edit** > **Categories**.
- 5 Enter one or more category names, separated by commas.
- 6 If necessary, select a suggested category.
- 7 Select **Done**.

### Deleting a Saved Location

**NOTE:** Deleted locations cannot be recovered.

- 1 Select **Where To?** > **Saved**.
- 2 Select **≡** > **Delete Saved Places**.
- 3 Select the box next to the saved locations to delete, and select **Delete**.

### Setting a Simulated Location

If you are indoors or not receiving satellite signals, you can use the GPS to set a simulated location.

- 1 Select **Settings** > **Navigation** > **GPS Simulator**.
- 2 From the main menu, select **View Map**.
- 3 Tap the map twice to select an area.
 

The address of the location appears at the bottom of the screen.
- 4 Select the location description.
- 5 Select **Set Location**.

### Adding a Shortcut

You can add shortcuts to the Where To? menu. A shortcut can point to a location, a category, or a search tool.

The Where To? menu can contain up to 36 shortcut icons.

- 1 Select **Where To?** > **Add Shortcut**.
- 2 Select an item.

### Removing a Shortcut

- 1 Select **Where To?** > **≡** > **Remove Shortcut(s)**.
- 2 Select the shortcut to remove.
- 3 Select the shortcut again to confirm.

### Custom Points of Interest

Custom POIs are customized points on the map. They can contain alerts that let you know if you are near a designated point or if you are traveling faster than a specified speed.

### Installing POI Loader

You can create or download custom POI lists on your computer and install them on your device using POI Loader software.

- 1 Go to [www.garmin.com/poiloader](http://www.garmin.com/poiloader).
- 2 Follow the on-screen instructions.

### Using the POI Loader Help Files

For more information on the POI loader, refer to the Help file.

With the POI loader open, click **Help**.

### Finding Custom POIs

Before you can find custom POIs, you must load custom POIs on your device using the POI Loader software (page 4).

- 1 Select **Where To?** > **Categories**.
- 2 Scroll to the Other Categories section, and select a category.

## Navigation

### Starting a Route

- 1 Search for a location (page 2).
- 2 Select a location.
- 3 Select **Go!**.

### Previewing Multiple Routes

- 1 Search for a location (page 2).
- 2 From the search results, select a location.
- 3 Select **Routes**.
- 4 Select a route.

### Changing the Route Calculation Mode

The route calculation is based on road speeds and vehicle acceleration data for a given route. The calculation mode affects only automobile routes.

Select **Settings** > **Navigation** > **Calculation Mode**.

- Select **Faster Time** to calculate routes that are faster to drive but can be longer in distance.
- Select **Shorter Distance** to calculate routes that are shorter in distance but can take more time to drive.
- Select **Off Road** to calculate point-to-point routes (without roads).

### Navigating Off Road

If you are not following roadways as you navigate, you can use Off Road mode.

- 1 Select **Settings** > **Navigation**.
- 2 Select **Calculation Mode** > **Off Road** > **Save**.

The next route will be calculated as a straight line to the location.

### Starting a Route to a Saved Location

- 1 Select **Where To?** > **Saved**.
- 2 If necessary, select a category, or select **All Saved Places**.
- 3 Select a location.
- 4 Select **Go!**.

### Your Route on the Map

#### NOTICE

The speed limit feature is for information only and does not replace your responsibility to abide by all posted speed limit signs and to use safe driving judgment at all times. Garmin will not be responsible for any traffic fines or citations you receive for failing to follow all applicable traffic laws and signs.



The route is marked with a magenta line. A checkered flag marks your destination.

As you travel, the device guides you to the destination with voice prompts, arrows on the map, and directions at the top of the map. If you depart from the original route, the device recalculates the route and provides new directions.

A data field displaying the current speed limit may appear as you travel on major roadways.



## Using the Navigation Map

- 1 Select **View Map**.
- 2 Select anywhere on the map.
- 3 Select an option:
  - To zoom in or out, select **+** or **-**.
  - To switch between North Up and 3-D views, select **▲**.
  - To view specific categories when not navigating a route, select **Q**.
  - To center the map on your current location, select **📍**.

## Adding a Point to a Route

Before you can add a stop, you must be navigating a route.

- 1 From the map, select **📍 > Where To?**
- 2 Search for the extra stop.
- 3 Select the stop from the search results.
- 4 Select **Go!**.
- 5 Select **Add to Active Route**.

## Taking a Detour

Before you can take a detour, you must add the detour tool to the map tools menu ([page 6](#)).

You can take a detour for a specified distance along your route or detour around specific roads. This is useful if you encounter construction zones, closed roads, or poor road conditions.

- 1 While navigating a route, from the map select **☰ > Detour**.
- 2 Select an option.
  - To detour your route for a specific distance, select **0.5 mi**, **2 mi**, or **5 mi**.
  - To detour around a specific road on the route, select **🛣️**.
- 3 If necessary, select a road to detour around.

## Stopping the Route

From the map, select **☰ > ⓧ**.

## Viewing Route Activity

### Viewing a List of Turns

While navigating a route, you can view all of the turns and maneuvers for your entire route and the distance between turns.

- 1 While navigating a route, select the text bar on the top of the map.
- 2 Select a turn.

The details for the turn appear. If available, an image of the junction appears for junctions on major roadways.

### Viewing the Entire Route on the Map

- 1 While navigating a route, select the navigation bar at the top of the map.
- 2 Select **☰ > Map**.

### Viewing the Next Turn

While navigating an automobile route, a preview of the next turn, lane change, or other maneuver appears in the upper-left corner of the map.

The preview includes the distance to the turn or maneuver and the lane in which you should be traveling, if available.

From the map, select **📏 0.8** to view the next turn on the map.

### Active Lane Guidance

As you approach a turn while navigating a route, a detailed simulation of the road appears beside the map, if available. A colored line indicates the proper lane for the turn.

### Viewing Junctions

While navigating a route, you can view the junctions on major roadways. When you approach a junction in a route, the image of that junction appears briefly, if available.

From the map, select **📏 0.8** to view the junction, if available.

## About Up Ahead

You can view upcoming businesses and services along your route or the road on which you are traveling.

Services are listed under tabs by category.

	Gas
	Food
	Lodging
	Restrooms
	Parking
	Banks and ATMs

### Finding Upcoming Points of Interest

- 1 From the map, select **☰ > Up Ahead**.
- 2 Select a tab.
- 3 Select a point of interest.

### Customizing the Up Ahead Categories

You can change the categories you search for, rearrange the order of the categories, and search for a specific business or category.

- 1 From the map, select **☰ > Up Ahead**.
- 2 Select a service icon.
- 3 Select **↕**.
- 4 Select an option:
  - To move the a category up or down in the list, select and drag the arrow to the right of the category name.
  - To change a category, select the category.
  - To create a custom category, select a category, select **Custom Search**, and enter the name of a business or category.
- 5 Select **Done**.

## Trip Information

### Viewing Trip Data from the Map

Before you can view trip data on the map, you must add the tool to the map tools menu. See [page 6](#).

From the map, select **☰ > Trip Data**.

### Customizing the Trip Data Fields

Before you can customize the data that appears in the trip data fields on the map, you must add the Trip Data tool to the map tools menu (page 6).

- 1 Select **View Map**.
- 2 Select **☰ > Trip Data**.
- 3 Select a trip data field.
- 4 Select an option.

The new trip data field appears in the trip data list.

### Viewing the Trip Information Page

The trip information page displays your present speed and provides statistics about your trip.

**NOTE:** If you make frequent stops, leave the device turned on, so it can accurately measure elapsed time during the trip.

From the map, select **Speed**.



### Viewing the Trip Log

Your device keeps a trip log, which is a record of the path you have traveled.

- 1 Select **Settings > Map & Vehicle > Map Layers**.
- 2 Select the **Trip Log** check box.

### Resetting Trip Information

- 1 From the map, select **Speed**.
- 2 Select **☰ > Reset Field(s)**.
- 3 Select an option:
  - When not navigating a route, select **Select All** to reset every data field except the speedometer, on the first page.
  - Select **Reset Trip Data** to reset the information on the trip computer.
  - Select **Reset Max. Speed** to reset the maximum speed.
  - Select **Reset Trip B** to reset the odometer.

### Using Suggested Routes

Before you can use this feature, you must save at least one location and enable the travel history feature (page 13).

Using the myTrends™ feature, your device predicts your destination based on your travel history, the day of the week, and the time of day. After you have driven to a saved location several times, the location may appear in the navigation bar on the map, along with the estimated time of travel, and traffic information.

Select the navigation bar to view a suggested route to the location.

### Viewing Current Location Information

You can use the Where Am I? page to view information about your current location. This feature is helpful if you need to tell emergency personnel your location.

From the map, select the vehicle.

### Finding Nearby Services

You can use the Where Am I? page to find nearby services, such as fuel, hospitals or police stations.

- 1 From the map, select the vehicle.
- 2 Select a category.

### Getting Directions to Your Current Location

If you need to tell another person how to get to your current location, your device can give you a list of directions.

- 1 From the map, select the vehicle.
- 2 Select **☰ > Directions to Me**.
- 3 Select a starting location.
- 4 Select **Select**.

### Avoiding Road Features

- 1 Select **Settings > Navigation > Avoidances**.
- 2 Select the road features to avoid on your routes, and select **Save**.

### About Custom Avoidances

Custom avoidances allow you to avoid specific areas and sections of road. You can enable and disable custom avoidances as needed.

#### Avoiding an Area

- 1 Select **Settings > Navigation > Custom Avoidances**.
- 2 If necessary, select **Add Avoidances**.
- 3 Select **Add Avoid Area**.
- 4 Select the upper-left corner of the area to avoid, and select **Next**.
- 5 Select the lower-right corner of the area to avoid, and select **Next**.

The selected area is shaded on the map.
- 6 Select **Done**.

#### Avoiding a Road

- 1 Select **Settings > Navigation > Custom Avoidances**.
- 2 Select **Add Avoid Road**.
- 3 Select the starting point of the section of road to avoid, and select **Next**.
- 4 Select the ending point of the road section, and select **Next**.
- 5 Select **Done**.

#### Disabling a Custom Avoidance

You can disable a custom avoidance without deleting it.

- 1 Select **Settings > Navigation > Custom Avoidances**.
- 2 Select an avoidance.
- 3 Select **☰ > Disable**.

#### Deleting Custom Avoidances

- 1 Select **Settings > Navigation > Custom Avoidances**.
- 2 Select an option:
  - To delete all custom avoidances, select **☒**.
  - To delete one custom avoidance, select the avoidance, and select **☰ > Delete**.

### Customizing the Map

#### Customizing the Map Tools

You can select the shortcuts that appear in the map tools menu.

- 1 Select **Settings > Map & Vehicle > Map Tools**.
- 2 Select the map tools to include in the menu.
- 3 Select **Save**.

#### Customizing the Map Layers

You can customize which data appear on the map, such as icons for points of interest and road conditions.

- 1 Select **Settings > Map & Vehicle > Map Layers**.
- 2 Select the layers to include on the map, and select **Save**.

### Changing the Map Data Field

- 1 From the map, select a data field.  
**NOTE:** You cannot customize **Speed**.
- 2 Select a type of data to display.
- 3 Select **Save**.

### Changing the Map Perspective

- 1 Select **Settings > Map & Vehicle > Driving Map View**.
- 2 Select an option:
  - Select **Track Up** to display the map in two dimensions (2-D), with your direction of travel at the top.
  - Select **North Up** to display the map in 2-D with north at the top.
  - Select **3-D** to display the map in three dimensions.

## Safety Cameras

### NOTICE

Garmin is not responsible for the accuracy of or the consequences of using a custom point of interest or a safety camera database.

Safety camera information is available in some locations. Check [www.garmin.com/safetycameras](http://www.garmin.com/safetycameras) for availability. For these locations, you can purchase a subscription for safety camera information. The subscription includes the locations of hundreds of safety cameras. Your device alerts you when you are approaching a safety camera and can warn you if you are driving too fast. The data is updated at least weekly, so you can update your device regularly to receive the most up-to-date information.

You can purchase a new region or extend an existing subscription at any time. Each region that you purchase has an expiration date.

## Traffic

### NOTICE

Garmin is not responsible for the accuracy or timeliness of the traffic information.

Traffic information may not be available in all areas or countries. For information about traffic receivers and coverage areas, go to [www.garmin.com/traffic](http://www.garmin.com/traffic).

A traffic receiver is included in some packages, built into either the vehicle power cable or the device, and is an optional accessory for all models.

- Traffic alerts appear on the map when there are traffic incidents along your route or in your area.
- You can receive traffic information through a traffic receiver or as a subscription service through Smartphone Link (page 10).
- The device must be connected to Smartphone Link with an active traffic subscription to receive traffic information through Smartphone Link.
- The device must be connected to vehicle power to receive traffic information through a traffic receiver.
- The powered traffic receiver and the device may need to be in data range of a station transmitting traffic data to receive traffic information.
- You do not need to activate the subscription included with your device or traffic receiver.

- If your device includes an external traffic antenna, you should always leave the external antenna plugged in for the best traffic reception.

## Receiving Traffic Data Using a Traffic Receiver

### NOTICE

Heated (metallized) windshields could degrade the performance of the traffic receiver.

Before you can receive traffic data using a traffic receiver, you must have a traffic-compatible power cable. If your device model includes lifetime traffic, you should use the vehicle power cable packaged with your device. If your device model does not include traffic, you must purchase a Garmin traffic receiver accessory. Go to [www.garmin.com/traffic](http://www.garmin.com/traffic) for more information.

Your device can receive traffic signals from a station broadcasting traffic data.

**NOTE:** In some areas, traffic information may be received from FM radio stations using HD Radio™ technology.

- 1 Connect the traffic-compatible power cable to an external power source.
- 2 Connect the traffic-compatible power cable to the device.

When you are within a traffic coverage area, your device displays traffic information.

### Traffic Receiver



①	Mini-USB connector
②	External antenna connector
③	Internal antenna
④	Power LED
⑤	Vehicle power adapter

### Positioning the Traffic Receiver

You can position the traffic receiver power cable for optimal traffic reception.

- 1 Uncoil the cable.
- 2 Place the middle of the cable in a location with an unobstructed view of the sky, such as the dash.  
**NOTE:** Do not rest the cable on the cable plug that connects to the vehicle power source.  
Do not place the cable on the floor or underneath other objects.

### Viewing Upcoming Traffic

You can view traffic incidents coming up along your route or along the road on which you are traveling.

- 1 While navigating a route, select **☰ > Traffic**.  
The nearest upcoming traffic incident appears in a panel on the right side of the map.
- 2 Select the traffic incident to view additional details.


### Viewing Traffic on the Map

The traffic map shows color-coded traffic flow and delays on nearby roads.

- 1 From the main menu, select **Apps > Traffic**.

- 2 If necessary, select  > **Legend** to view the legend for the traffic map.

### Searching for Traffic Incidents


- 1 From the main menu, select **Apps** > **Traffic**.
- 2 Select  > **Incidents**.
- 3 Select an item in the list.
- 4 If there is more than one incident, use the arrows to view additional incidents.

### Traffic on Your Route

When a traffic delay occurs on your route, an alert appears on the map, and the device calculates an alternate route to avoid the delay. You can choose whether to use alternate routes automatically, or upon request. See Traffic Settings for more information (page 13). Your device may route you through a traffic delay if a better alternative route does not exist. The delay time is added into your estimated time of arrival automatically.

### Taking an Alternate Route

If you do not have your device set to use alternate routes automatically, you can manually start an alternate route to avoid a traffic delay.

- 1 While navigating a route, select  > **Traffic**.
- 2 Select **Alternate Route**.  
**NOTE:** If a better alternative route does not exist, this option is not available, and **On Fastest Route** appears instead.
- 3 Select **Go!**.

### About Traffic Cameras

Traffic cameras provide live images of traffic conditions on major roadways and intersections. You can save cameras that you want to view regularly.

### Saving a Traffic Camera

Before you can use this feature, you must subscribe to the photoLive service, and your device must be connected to a supported phone running Smartphone Link (page 10).

This feature is not available in all areas.

- 1 Select **Apps** > **photoLive**.
- 2 Select **Touch to Add**.
- 3 Select a road.
- 4 Select an intersection.
- 5 Select **Touch to Add**.

### Viewing a Traffic Camera

Before you can view a traffic camera, you must save a traffic camera (page 8).

- 1 Select **Apps** > **photoLive**.
- 2 Select a camera.

### About Traffic Subscriptions

You can purchase additional subscriptions or a renewal if your subscription expires. Go to <http://www.garmin.com/traffic>.

### Subscription Activation

You do not need to activate the subscription included with your FM traffic receiver. The subscription activates automatically after your device acquires satellite signals while receiving traffic signals from the pay service provider.

### Viewing Traffic Subscriptions

Select **Settings** > **Traffic** > **Subscriptions**.

### Adding a Subscription

You can purchase traffic subscriptions for other regions or countries.

- 1 From the main menu, select **Traffic**.
- 2 Select **Subscriptions** > **+**.
- 3 Write down the FM traffic receiver unit ID.
- 4 Go to [www.garmin.com/fmtraffic](http://www.garmin.com/fmtraffic) to purchase a subscription and get a 25-character code.  
The traffic subscription code cannot be reused. You must obtain a new code each time you renew your service. If you own multiple FM traffic receivers, you must obtain a new code for each receiver.
- 5 Select **Next** on the device.
- 6 Enter the code.
- 7 Select **Done**.

### trafficTrends™

When the trafficTrends feature is enabled, your device uses historic traffic data to calculate more-efficient routes.

**NOTE:** Different routes may be calculated based on traffic trends for the day of the week or the time of day.

### Disabling trafficTrends

To prevent your device from recording or sharing traffic data, you must disable trafficTrends.

Select **Settings** > **Traffic** > **trafficTrends**.

### Enabling Traffic

You can enable or disable traffic data. When traffic data is disabled, the device does not receive traffic data, but it still avoids potentially congested areas in routes using the trafficTrends feature, if enabled (page 8).

- 1 Select **Settings** > **Traffic**.
- 2 Select the **Traffic** check box.

## Voice Command

**NOTE:** Voice command is not available for all languages and regions, and may not be available on all models.

**NOTE:** Voice Activated Navigation may not achieve desired performance when in a noisy environment.

Voice command allows you to use your device by saying words and commands. The voice command menu provides voice prompts and a list of available commands.

### Setting the Wakeup Phrase

The wakeup phrase is a word or phrase you can say to activate voice command. The default wakeup phrase is **Voice Command**.

**TIP:** You can reduce the chance of accidental voice command activation by using a strong wakeup phrase.

- 1 Select **Apps** > **Voice Command** > **Customize Phrase**.

- 2 Enter a new wakeup phrase.

The device indicates the strength of the wakeup phrase as you enter the phrase.

- 3 Select **Done**.

### Activating Voice Command

Say your wakeup phrase.

The voice command menu appears.

### Voice Command Tips

- Speak in a normal voice directed at the device.
- Reduce background noise, such as voices, or the radio, to increase the accuracy of the voice recognition.
- Speak commands as they appear on the screen.

- Respond to voice prompts from the device as needed.
- Increase the length of your wakeup phrase to reduce the chance of accidental voice command activation.
- Listen for two tones to confirm when the device enters and exits voice command.


## Starting a Route Using Voice Command

You can say the names of popular, well-known locations.

- 1 Say your wakeup phrase (page 8).
- 2 Say **Find Place**.
- 3 Listen for the voice prompt, and speak the name of the location.
- 4 Say the line number.
- 5 Say **Navigate**.

## Muting Instructions

You can disable the voice prompts for voice command without muting the device.

- 1 Select **Apps > Voice Command > **.
- 2 Select **Mute Instructions > Enabled**.

## Disabling Voice Command

You can disable voice command, which prevents you from accidentally activating voice command while speaking.

- 1 Select **Apps > Voice Command > **.
- 2 Select **Voice Command > Disabled**.

# Hands-Free Phone Calls

## About Hands-Free Calling

**NOTE:** Bluetooth wireless technology is not available on all models, or for all languages and regions.

Hands-free calling is available on some models. Using Bluetooth wireless technology, your device can connect to your mobile phone to become a hands-free device. To determine whether your mobile phone with Bluetooth technology is compatible with your device, go to [www.garmin.com/bluetooth](http://www.garmin.com/bluetooth).


Your phone may not support all of the hands-free phone features your device provides.

### Enabling Bluetooth Wireless Technology

- 1 Select **Settings > Bluetooth**.
- 2 Select **Bluetooth**.

### Pairing Your Phone

Before you can use hands-free calling, you must pair your device with a compatible mobile phone.

- 1 Place your phone and your Bluetooth device within 33 ft. (10 m) of each other.
- 2 On your device, enable Bluetooth wireless technology.
- 3 Select an option:
  - Select **Settings > Bluetooth > Add Phone**.
  - If you have already paired a different phone, select **Settings > Bluetooth > Phone > **.
- 4 On your phone, enable Bluetooth wireless technology.
- 5 On your device, select **OK**.  
A list of nearby Bluetooth devices appears.
- 6 Select your phone from the list, and select **OK**.
- 7 If necessary, on your phone, confirm that the device is allowed to connect.
- 8 If necessary, enter the device Bluetooth PIN into your phone.

## Tips After Pairing the Devices

- After the initial pairing, the two devices can connect automatically each time you turn them on.
- When your phone is connected to your device, you are ready to receive voice calls.
- When you turn on the device, it tries to connect to the last phone to which it was connected.
- You might need to set your phone to connect to the device automatically when the device is turned on.


## Disconnecting Your Phone

- 1 Select **Settings > Bluetooth**.
- 2 Select **Phone > None > Save**.

Your phone is disconnected from your device but remains paired with your device.

## Deleting a Paired Phone

You can delete a paired phone to prevent it from automatically connecting to your device in the future.

- 1 Select **Settings > Bluetooth > Phone**.
- 2 Select .
- 3 Select the phone, and select **Delete**.

## Placing a Call

### Dialing a Number

- 1 Select **Apps > Phone > Dial**.
- 2 Enter the number.
- 3 Select **Dial**.

### Calling a Contact in Your Phone Book

Your phone book is loaded from your phone to the device each time your phone and the device connect. It may take a few minutes for the phone book to be available. Some phones do not support this feature.

- 1 Select **Apps > Phone > Phone Book**.
- 2 Select a contact.
- 3 Select **Call**.

### Calling a Location

- 1 Select **Apps > Phone > Browse Categories**.
- 2 Select a point of interest.
- 3 Select **Call**.

## Receiving a Call


When you receive a call, select **Answer** or **Ignore**.

## Using the Call History

Your call history is loaded from your phone to the device each time your phone and the device connect. It may take a few minutes for the call history to be available. Some phones do not support this feature.

- 1 Select **Apps > Phone > Call History**.
- 2 Select a category.  
A list of calls appears, with the most recent calls at the top.
- 3 Select a call.

## Using In-Call Options

- 1 From the map, while on a call, select .
- 2 Select an option.
  - To transfer audio to your phone, select **Handset**.  
**TIP:** You can use this feature if you want to turn off your device and remain on the call, or if you need privacy.

**TIP:** You can use this feature to use automated systems, such as voice mail.

- To mute the microphone, select **Mute**.
- To hang up, select **End Call**.

## Saving a Home Phone Number

**TIP:** After you save a home number, you can edit the home number by editing “Home” in your list of saved locations (page 3).

- 1 Select **Apps > Phone > ≡ > Set Home Number**.
- 2 Enter your phone number.
- 3 Select **Done**.

### Calling Home

Before you can call home, you must enter a phone number for your home location.

Select **Saved > Home > ≡ > Call**.

## Using the Apps

### Using Help

Select **Apps > Help** to view information about using the device.

### Searching Help Topics

Select **Apps > Help > Q**.

## Smartphone Link

Smartphone Link is a phone application that allows you to synchronize location data with your phone and access live information using your phone data connection. Your device transfers data from Smartphone Link using Bluetooth wireless technology. Live information is available through free and subscription-based plans from Garmin Live Services (page 10).

Saved locations and recently found locations are synchronized with your phone each time your device connects to Smartphone Link.

### Downloading Smartphone Link

Smartphone Link is available for some smartphones. Go to [www.garmin.com/smartphonelink](http://www.garmin.com/smartphonelink) or see the application store for your phone for compatibility and availability information.

Download Smartphone Link from the application store on your supported phone.

See your phone owner's manual for information on downloading and installing applications.

### Connecting to Smartphone Link

Before you can connect to Smartphone Link, you must download and install the Smartphone Link application on your phone.

- 1 Start Smartphone Link on your phone.
- 2 From your device, select **Settings > Bluetooth**, and select the **Bluetooth** check box.
- 3 From your phone, select **Bluetooth Settings**.
- 4 From your phone, enable Bluetooth wireless technology, and scan for nearby Bluetooth devices.  
See your phone owner's manual for more information.
- 5 From your phone, select your device from the list of nearby devices.
- 6 Follow the on-screen instructions on your phone and on your device to confirm the pairing request.

☒ appears in the status bar on your device when Smartphone Link is connected.

## Sending a Location from Your Phone to Your Device

Smartphone Link is registered as a navigation application on your phone.

- 1 From your phone, select the button to start navigating to a location (see the owner's manual for your phone).
- 2 From the application menu, select **Smartphone Link**.

The next time you connect your device to your phone, the location is transferred to the recently found items on your device.

## Disabling Calls While Connected to Smartphone Link

While the device is connected to the phone and receiving Garmin Live Services, you can disable hands-free calling.

- 1 Select **Apps > Smartphone Link**.
- 2 Select your phone.
- 3 Clear the **Hands-Free Calling** check box.

## Garmin Live Services

Before you can use Garmin Live Services, your device must be connected to a supported phone running Smartphone Link (page 10).

Connecting to Smartphone Link provides access to Garmin Live Services. Garmin Live Services provides free and subscription-based plans to view live data on your device, such as traffic conditions and weather.

Some services, like weather, are available as separate apps on your device. Other services, like traffic, enhance the existing navigation features on your device. Features that require access to Garmin Live Services display the Smartphone Link symbol and appear only when the device is connected to Smartphone Link.

### Subscribing to Garmin Live Services

Before you can subscribe to Garmin Live Services, you must install the Smartphone Link app on your phone.

- 1 Start the Smartphone Link app on your phone (page 10).
- 2 Select **Garmin Live Services**.  
A list of services and subscription prices appears.
- 3 Select a service.
- 4 Select the price.
- 5 Select **Subscribe**.
- 6 Follow the on-screen instructions.

## About ecoRoute

In some areas, before you can use ecoRoute™ features, you must purchase an unlock code or an ecoRoute HD accessory. Go to [www.garmin.com/ecoroute](http://www.garmin.com/ecoroute) for more information.

The ecoRoute feature calculates the fuel economy and the fuel price of navigating to a destination, and offers tools for improving fuel efficiency.

The data provided by the ecoRoute feature is an estimate only. The data is not actually read from the vehicle, unless you are using the ecoRoute HD accessory.

To receive more-accurate fuel reports for your specific vehicle and driving habits, calibrate the fuel economy (page 11).

### ecoRoute HD Accessory

When connected to the ecoRoute HD accessory, your device can receive real-time vehicle information, such as error messages, RPM, and battery voltage. Your device includes data read from the vehicle by the ecoRoute HD accessory when calculating ecoRoute data.

The ecoRoute HD accessory is compatible only with devices that have Bluetooth wireless technology.

Go to [www.garmin.com/ecoRoute](http://www.garmin.com/ecoRoute).

## Setting Up the Vehicle

The first time you use the ecoRoute features, you must enter vehicle information.

- 1 Select **Apps > ecoRoute**.
- 2 Follow the on-screen instructions.

## Changing the Fuel Price

- 1 Select **Apps > ecoRoute > At the Pump**.
- 2 Enter the current price of fuel, and select **Next**.
- 3 Select **Yes**.

## Calibrating the Fuel Economy

You can calibrate the fuel economy to receive more-accurate fuel reports for your specific vehicle and driving habits. You should calibrate when you fill up your fuel tank.

- 1 Select **Apps > ecoRoute > At the Pump**.
- 2 Enter the current fuel price.
- 3 Enter the amount of fuel the vehicle has used since the last time the fuel tank was filled.
- 4 Enter the distance you have traveled since the last time the fuel tank was filled.
- 5 Select **Next**.  
The device calculates the average vehicle fuel economy.
- 6 Select **Save**.

## About ecoChallenge

ecoChallenge helps you maximize the vehicle fuel economy by scoring your driving habits. The higher your ecoChallenge scores, the more fuel you have saved. The ecoChallenge collects data and calculates a score whenever your device is moving and in Automobile transportation mode.

### Viewing ecoChallenge Scores

Select **Apps > ecoRoute > ecoChallenge**.

### About the ecoChallenge Score

**Acceleration:** Displays your score for smooth and gradual acceleration. You lose points for rapid acceleration.

**Braking:** Displays your score for smooth and gradual braking. You lose points for hard braking.

**Overall:** Displays an average of the speed, acceleration, and braking score.

**Speed:** Displays your score for driving your vehicle at the optimal speed for conserving fuel.

### Resetting the ecoChallenge Scores

- 1 Select **Apps > ecoRoute > ecoChallenge**.
- 2 Select **≡ > Reset**.

## Viewing Fuel Economy Information

- 1 Select **Apps > ecoRoute > Fuel Economy**.
- 2 Select a section of the graph to zoom in.

## Mileage Reports

Mileage reports provide the distance, the time, the average fuel economy, and the fuel cost of navigating to a destination.

A mileage report is created for every route that you drive. If you stop a route on your device, a mileage report is created for the distance you traveled.

### Viewing a Mileage Report

You can view saved mileage reports on the device.

**TIP:** You can connect the device to your computer and access mileage reports in the Reports folder on the device.

- 1 Select **Apps > ecoRoute > Mileage Report**.
- 2 Select a report.

## Resetting ecoRoute Information

- 1 Select **Apps > ecoRoute > Vehicle Profile**.
- 2 Select **≡ > Reset**.

## Viewing myGarmin Messages

Before you can use this feature, your device must be connected to a supported phone running Smartphone Link ([page 10](#)). This feature is not available in all areas.

You can view messages from myGarmin, such as notifications for software and map updates.

- 1 Select **Apps > myGarmin**.  
If you have unread messages, the number of unread messages appears on the myGarmin icon.
- 2 Select a message subject.  
The full message appears.

## Viewing the Weather Forecast

Before you can use this feature, your device must be connected to a supported phone running Smartphone Link ([page 10](#)). This feature is not available in all areas.

- 1 Select **Apps > Weather**.
- 2 Select a day.  
The detailed forecast for that day appears.

## Viewing Weather Near a Different City

- 1 Select **Apps > Weather > Current Location**.
- 2 Select an option:
  - To view weather for a favorite city, select a city in the list.
  - To add a favorite city, select **Add City**, and enter a city name.

## Viewing the Weather Radar

You can view an animated, color-coded radar map of current weather conditions, as well as a weather icon on the map. The weather icon changes to show weather in the vicinity, such as rain, snow, and thunderstorms.

- 1 Select **Apps > Weather**.
- 2 If necessary, select a city.
- 3 Select **≡ > Weather Radar**.

## Viewing Weather Alerts

While you are traveling with your device, weather alerts may appear on the map. You can also view a map of weather alerts near your current location or near a selected city.

- 1 Select **Apps > Weather**.
- 2 If necessary, select a city.
- 3 Select **≡ > Weather Alerts**.

## Checking Road Conditions

- 1 Select **Apps > Weather**.
- 2 If necessary, select a city.
- 3 Select **≡ > Road Conditions**.

## Planning a Trip

You can use the trip planner to create and save a trip with multiple destinations.

- 1 Select **Apps > Trip Planner**.
- 2 Select **New Trip**.
- 3 Select **Select Start Location**.
- 4 Search for a location ([page 2](#)).

- 5 Select **Select**.
- 6 To add additional locations, select **+**.
- 7 Select **Next**.
- 8 Enter a name, and select **Done**.

### Scheduling a Trip

You can use the trip planner to create and save a trip with multiple destinations.

- 1 Select **Apps > Trip Planner**.
- 2 Select a trip.
- 3 Select a location.
- 4 Select an option:
  - Select **Departure Time**.
  - Select **Arrival Time**.
- 5 Select a date and time, and select **Save**.
- 6 Select **Duration**.
- 7 Select the amount of time you will spend at the location, and select **Save**.
- 8 If necessary, repeat steps 3–7 for each location.

### Navigating to a Saved Trip

- 1 Select **Apps > Trip Planner**.
- 2 Select a saved trip.
- 3 Select **Go!**.
- 4 If prompted, select a route ([page 4](#)).

### Editing a Saved Trip

- 1 Select **Apps > Trip Planner**.
- 2 Select a saved trip.
- 3 Select **≡**.
- 4 Select an option:
  - Select **Rename Trip**.
  - Select **Edit Destinations** to add and delete a location, or to change the order of locations.
  - Select **Delete Trip**.
  - Select **Optimize Order** to arrange the stops on your trip in the most-efficient order.

## Viewing Previous Routes and Destinations

Before you can use this feature, you must enable the travel history feature ([page 13](#)).

You can view your previous routes and places you have stopped on the map.

Select **Apps > Where I've Been**.

## Data Management

You can store files on your device. The device has a memory card slot for additional data storage.

**NOTE:** The device is not compatible with Windows® 95, 98, Me, Windows NT®, and Mac® OS 10.3 and earlier.

### File Types

The device supports these file types.

- Maps and GPX waypoint files from myGarmin™ mapping software, including MapSource®, BaseCamp™, and HomePort™ ([page 4](#)).
- GPI custom POI files from Garmin POI Loader ([page 4](#)).

## About Memory Cards

You can purchase memory cards from an electronics supplier, or purchase pre-loaded Garmin mapping software ([www.garmin.com/trip\\_planning](http://www.garmin.com/trip_planning)). In addition to map and data storage, the memory card can be used to store files such as maps, images, geocaches, routes, waypoints, and custom POIs.

### Installing a Memory Card

The device supports microSD™ and microSDHC memory cards.

- 1 Insert a memory card into the slot on the device.
- 2 Press it in until it clicks.

## Connecting the Device to Your Computer

You can connect the device to your computer using the USB cable included with your device.

- 1 Plug the small end of the USB cable into the port on the device.
- 2 Plug the larger end of the USB cable into a port on your computer.

A picture of your device connected to a computer appears on the device screen.

Depending on your computer operating system, the device appears as either a portable device, a removable drive, or a removable volume.

## Transferring Data From Your Computer

- 1 Connect the device to your computer ([page 12](#)).

Depending on your computer operating system, the device appears as either a portable device, a removable drive, or a removable volume.

- 2 On your computer, open the file browser.
- 3 Select a file.
- 4 Select **Edit > Copy**.
- 5 Browse to a folder on the device.

**NOTE:** For a removable drive or volume, you should not place files in the Garmin folder.

- 6 Select **Edit > Paste**.

### Disconnecting the USB Cable

If your device is connected to your computer as a removable drive or volume, you must safely disconnect your device from your computer to avoid data loss. If your device is connected to your Windows computer as a portable device, it is not necessary to safely disconnect.

- 1 Complete an action:
  - For Windows computers, select the **Safely Remove Hardware** icon in the system tray, and select your device.
  - For Mac computers, drag the volume icon to the trash.
- 2 Disconnect the cable from your computer.

## Customizing the Device

### Map and Vehicle Settings

To open the Map and Vehicle settings, from the main menu, select **Settings > Map & Vehicle**.

**Vehicle:** Changes the icon to represent your position on the map. Go to [www.garmin.com](http://www.garmin.com) for more icons.

**Driving Map View:** Sets the perspective on the map.

**Map Detail:** Sets the level of detail on the map. More detail may cause the map to draw slower.

**Map Theme:** Changes the color of the map data.



**Map Tools:** Selects the shortcuts that appear in the map tools menu.

**Map Layers:** Sets the data that appears on the map page (page 6).

**myMaps:** Sets which installed maps the device uses.

### Enabling Maps

You can enable map products installed on your device.

**TIP:** To purchase additional map products, go to [www.garmin.com/us/maps](http://www.garmin.com/us/maps).

- 1 Select **Settings > Map & Vehicle > myMaps**.
- 2 Select a map.

## Navigation Settings

To open the Navigation settings page, from the main menu, select **Settings > Navigation**.

**Calculation Mode:** Sets route preference.

**Avoidances:** Sets road features to avoid on a route.

**Custom Avoidances:** Allows you to avoid specific roads or areas.

**Advanced Detours:** Sets the length of the detour.

**Safe Mode:** Disables all functions that require significant operator attention and could become a distraction while driving.

**GPS Simulator:** Stops the device from receiving a GPS signal, and saves battery power.

### Route Preferences

To open the Calculation Mode settings page, from the main menu, select **Settings > Navigation > Calculation Mode**.

The route calculation is based on road speeds and vehicle acceleration data for a given route.

**Faster Time:** Calculates routes that are faster to drive but can be longer in distance.

**Shorter Distance:** Calculates routes that are shorter in distance but can take more time to drive.

**Less Fuel:** Calculates routes that could use less fuel than other routes.

**Off Road:** Calculates a direct line from your location to your destination.

## Display Settings

To open the Display settings page, from the main menu, select **Settings > Display**.

**Color Mode:** Changes the brightness of the screen. Decreasing the brightness can save battery power.

**Display Timeout:** Sets the amount of idle time before your device enters sleep mode.

**Brightness:** Adjusts the display brightness.

**Screenshot:** Allows you to take a picture of the device screen. Screenshots are saved in the **Screenshot** folder of the device storage.

## Bluetooth Settings

To open the Bluetooth settings, from the main menu, select **Settings > Bluetooth**.

**Bluetooth:** Enables Bluetooth wireless technology.

**Add Phone:** Manages connection between your device and wireless headsets with Bluetooth wireless technology.

**Friendly Name:** Allows you to enter a friendly name that identifies your devices with Bluetooth wireless technology.

### Disabling Bluetooth

- 1 Select **Settings > Bluetooth**.

- 2 Select **Bluetooth**.

## Traffic Settings

To open the traffic settings page, from the main menu, select **Settings > Traffic**.

**Traffic:** Enables traffic.

**Current Provider:** Sets the traffic provider to use for traffic data. **Auto** selects the best available traffic data automatically.

**Subscriptions:** Lists current traffic subscriptions.

**Optimize Route:** Selects whether to use optimized alternate routes automatically or upon request (page 8).

**Traffic Alerts:** Selects the traffic delay severity for which the device displays a traffic alert.

**trafficTrends:** Enables the trafficTrends feature (page 8).

## Units and Time Settings

To open the Units and Time settings page, from the main menu, select **Settings > Units & Time**.

**Current Time:** Sets the device time.

**Time Format:** Allows you to select a 12-hour, 24-hour, or UTC display time.

**Units:** Sets the unit of measure used for distances.

**Position Format:** Sets the coordinate format and datum used for geographical coordinates.

## Language and Keyboard Settings

To open the Language and Keyboard settings, from the main menu, select **Settings > Language & Keyboard**.

**Voice Language:** Sets the language for voice prompts.

**Text Language:** Sets all on-screen text to the selected language.

**NOTE:** Changing the text language does not change the language of user-entered data or map data, such as street names.

**Keyboard Language:** Sets the language for your keyboard.

## Device and Privacy Settings

To open the Device settings page, from the main menu, select **Settings > Device**.

**About:** Displays the software version number, the unit ID number, and information on several other software features.

**EULAs:** Displays the end-user license agreements that apply to your choice.

**NOTE:** You need this information when you update the system software or purchase additional map data.

**Travel History:** Allows the device to record information for the myTrends, Where I've Been, and Trip Log features.

**Clear Travel History:** Clears your travel history for the myTrends, Where I've Been, and Trip Log features.

## Proximity Alerts Settings

Select **Settings > Proximity Alerts**.


**Audio:** Sets the style of alert that plays when you approach proximity points.

**Alerts:** Sets the type of proximity points for which alerts are played.

## Restoring Settings

You can restore a category of settings or all settings to the factory default values.

- 1 Select **Settings**.

- 2 If necessary, select a settings category.
- 3 Select  > **Restore**.

## Appendix

### Power Cables

Your device can be powered various ways.

- Vehicle power cable
- USB cable
- AC adapter (optional accessory)

### Charging the Device

You can charge the battery in the device using any of these methods.

- Connect the device to the vehicle power cable.
- Connect the device to a computer using the included USB cable.
- Connect the device to an optional power adapter accessory, such as a wall power adapter.

### Changing the Fuse in the Vehicle Power Cable

#### NOTICE




When replacing the fuse, do not lose any of the small pieces and make sure they are put back in the proper position. The vehicle power cable does not work unless it is assembled correctly.

If your device does not charge in your vehicle, you may need to replace the fuse located at the tip of the vehicle adapter.

- 1 Unscrew the end piece .



**TIP:** You may need to use a coin to remove the end piece.

- 2 Remove the end piece, the silver tip , and the fuse .
- 3 Install a 2 A fast-blow fuse.
- 4 Place the silver tip in the end piece.
- 5 Screw the end piece back into the vehicle power cable .

### Device Care

#### NOTICE

Avoid dropping your device.

Do not store the device where prolonged exposure to extreme temperatures can occur, because it can cause permanent damage.

Never use a hard or sharp object to operate the touchscreen, or damage may result.

### Cleaning the Outer Casing

#### NOTICE

Avoid chemical cleaners and solvents that can damage plastic components.

- 1 Clean the outer casing of the device (not the touchscreen) using a cloth dampened with a mild detergent solution.
- 2 Wipe the device dry.

### Cleaning the Touchscreen

- 1 Use a soft, clean, lint-free cloth.
- 2 If necessary, lightly dampen the cloth with water.

- 3 If using a dampened cloth, turn off the device and disconnect the device from power.
- 4 Gently wipe the screen with the cloth.

### Avoiding Theft

- Remove the device and mount from sight when not in use.
- Remove the residue left on the windshield by the suction cup.
- Do not keep your unit in the glove compartment.
- Register your device at <http://my.garmin.com>.

### Mounting on Your Dashboard

#### NOTICE

The permanent mounting adhesive is extremely difficult to remove after it is installed.

Use the mounting disk to mount your device to the dashboard and comply with certain state regulations. See [www.garmin.com](http://www.garmin.com) for more information.

- 1 Clean and dry the dashboard where you are placing the disk.
- 2 Remove the backing from the adhesive on the bottom of the disk.
- 3 Place the disk on the dashboard.
- 4 Remove the clear plastic cover from the top of the disk.
- 5 Place the suction cup mount on top of the disk.
- 6 Flip the lever down (toward the disk).

### Removing the Device, Mount, and Suction Cup

#### Removing the Device from the Mount

- 1 Grip the device by the top and bottom.
- 2 Pull the bottom edge of the device toward you until it releases from the magnet.

Pulling the device straight toward you may cause the mount to release from the suction cup.

#### Removing the Mount from the Suction Cup

- 1 Turn the device mount to the right or left.
- 2 Apply pressure until the socket on the mount releases the ball on the suction cup.

#### Removing the Suction Cup from the Windshield

- 1 Flip the lever on the suction cup toward you.
- 2 Pull the tab on the suction cup toward you.

### Purchasing Additional Maps

- 1 Go to your device product page at ([www.garmin.com](http://www.garmin.com)).
- 2 Click the **Maps** tab.
- 3 Follow the on-screen instructions.

### Purchasing Accessories

Go to <http://buy.garmin.com>.

## Troubleshooting

### The suction cup will not stay on my windshield

- 1 Clean the suction cup and windshield with rubbing alcohol.
- 2 Dry with a clean, dry cloth.
- 3 Mount the suction cup ([page 1](#)).

## My device is not acquiring satellite signals

- Verify the GPS simulator is turned off ([page 13](#)).
- Take your device out of parking garages and away from tall buildings and trees.
- Remain stationary for several minutes.

## The device does not charge in my vehicle

- Check the fuse in the vehicle power cable ([page 14](#)).
- Verify the vehicle is turned on and is supplying power to the power outlet.
- Verify the interior temperature of the vehicle is between 32° and 113°F (between 0° and 45°C).
- Verify that the fuse is not broken in the vehicle power outlet.

## My battery does not stay charged for very long

- Decrease the screen brightness ([page 13](#)).
- Shorten the display timeout ([page 13](#)).
- Decrease the volume ([page 2](#)).
- Disable Bluetooth wireless technology ([page 13](#)).
- Put the device in sleep mode when not in use ([page 1](#)).
- Keep your device away from extreme temperatures.
- Do not leave your device in direct sunlight.

## The battery gauge does not seem accurate

- 1 Allow the device to fully discharge.
- 2 Fully charge the device without interrupting the charge cycle.

## My device does not appear as a removable drive on my computer

On most Windows computers, the device connects using Media Transfer Protocol (MTP). In MTP mode, the device appears as a portable device and not as a removable drive. MTP mode is supported by Windows 7, Windows Vista®, and Windows XP Service Pack 3 with Windows Media Player 10.

## My device does not appear as a portable device on my computer

On Mac computers and some Windows computers, the device connects using USB mass storage mode. In USB mass storage mode, the device appears as a removable drive or volume, and not as a portable device. Windows versions prior to Windows XP Service Pack 3 use USB mass storage mode.

## My device does not appear as either a portable device or a removable drive or volume on my computer

- 1 Disconnect the USB cable from your computer.
- 2 Turn off the device.
- 3 Plug the USB cable into a USB port on your computer and into your device.

**TIP:** Your device should be connected directly to a USB port on your computer and not to a USB hub.

The device automatically turns on and goes into MTP mode or USB mass storage mode. A picture of the device connected to a computer appears on the device screen.

## My phone will not connect to the device

- Select **Settings** > **Bluetooth**.

The Bluetooth field must be set to **Enabled**.

- Enable Bluetooth wireless technology on your phone and bring your phone within 33 feet (10 m) of the device.
- Go to [www.garmin.com/bluetooth](http://www.garmin.com/bluetooth) for more help.

# Index

## Symbols

2-D map view [7](#)  
3-D map view [7](#)

## A

accessories [14](#)  
active lane guidance [5](#)  
adding stops [5](#)  
addresses, finding [3](#)  
alerts  
  audio [13](#)  
  proximity points [13](#)  
  safety cameras [13](#)  
answering calls [9](#)  
audio, proximity points [13](#)  
automatic volume [2](#)  
  enabling [2](#)  
avoidances  
  area [6](#)  
  customizing [6](#)  
  deleting [6](#)  
  disabling [6](#)  
  road [6](#)  
  road features [6](#)

## B

battery  
  charging [1, 2, 14, 15](#)  
  maximizing [15](#)  
  problems [15](#)  
Bluetooth technology [9, 15](#)  
  disabling [13](#)  
  enabling [9](#)  
Bluetooth technology, settings [13](#)  
brightness [2](#)

## C

cables, power [14](#)  
calibrating fuel economy [11](#)  
calls [9](#)  
  answering [9](#)  
  call waiting [9](#)  
  contacts [9](#)  
  dialing [9](#)  
  disabling [10](#)  
  history [9](#)  
  home [10](#)  
  placing [9](#)  
cameras, safety [7](#)  
changing search area [3](#)  
charging the device [1, 2, 14, 15](#)  
cleaning the device [14](#)  
cleaning the touchscreen [14](#)  
computer, connecting [12, 15](#)  
coordinates [3](#)  
current location [6](#)  
custom POIs [4](#)  
customizing, avoidances [6](#)  
customizing the device [12](#)

## D

dashboard mount [14](#)  
deleting  
  paired headset [9](#)  
  trips [12](#)  
destinations. *See* locations  
detours [5](#)  
device care [14](#)  
dialing [9](#)  
directions [5](#)  
disconnecting phone [9](#)  
display settings [13](#)  
driving directions [5](#)

## E

ecoChallenge [11](#)  
ecoChallenge score [11](#)  
  resetting [11](#)

ecoRoute [11](#)  
  calibrating fuel economy [11](#)  
ecoChallenge score [11](#)  
  HD accessory [10](#)  
  mileage report [11](#)  
  mileage reports [11](#)  
  vehicle profile [11](#)  
ecoRoute HD, accessory [10](#)  
EULAs [13](#)  
extras  
  custom points of interest [4](#)  
  safety cameras [7](#)

## F

files  
  supported types [12](#)  
  transferring [12](#)  
finding locations. [2](#) *See also* locations  
  addresses [3](#)  
  browsing the map [3](#)  
  categories [2](#)  
  cities [3](#)  
  coordinates [3](#)  
  intersections [3](#)  
  using the map [3](#)  
finding services, up ahead [5](#)  
fuel, prices [11](#)  
fuel economy. [11](#) *See also* ecoRoute  
fuel price, changing [11](#)  
fuse, changing [14](#)

## G

Garmin Express [1](#)  
  registering the device [1](#)  
  updating software [1](#)  
Garmin Live Services [10](#)  
  subscribing to [10](#)  
geocaching [3](#)  
going home [3](#)  
GPS [1, 2](#)

## H

hands-free phone calls [9](#)  
help. [10](#) *See also* product support  
home  
  calling [10](#)  
  editing location [3](#)  
  going [3](#)  
  phone number [10](#)  
  setting locations [3](#)

## I

ID number [13](#)  
intersections, finding [3](#)

## J

junction view [5](#)

## K

keyboard [2](#)  
  language [13](#)  
  layout [13](#)

## L

language  
  keyboard [13](#)  
  voice [13](#)  
latitude and longitude [3](#)  
lifetime maps [1](#)  
locations [2, 3, 12](#)  
  calling [9](#)  
  current [3, 6](#)  
  recently found [3](#)  
  saving [3](#)  
  searching for [3](#)  
  setting home [3](#)  
  simulated [4](#)

## M

map, data field [7](#)  
map layers, customizing [6](#)

map perspective [7](#)  
map tools [6](#)  
map view  
  2-D [7](#)  
  3-D [7](#)  
maps [5, 13](#)  
  browsing [3](#)  
  data field [6](#)  
  detail level [12](#)  
  layers [6](#)  
  lifetime [1](#)  
  nüMaps Guarantee [1](#)  
  nüMaps Lifetime [1](#)  
  purchasing [14](#)  
  theme [12](#)  
  updating [1](#)  
  viewing routes [5](#)  
memory card [12](#)  
microSD card, installing [12](#)  
mileage reports [11](#)  
mount, removing [14](#)  
mounting the device  
  automobile [1](#)  
  dashboard [14](#)  
  removing from mount [14](#)  
  suction cup [1, 14](#)  
muting, audio [9](#)  
myGarmin, messages [11](#)  
myTrends, routes [6](#)

## N

navigation [4](#)  
  off-road [4](#)  
  previewing routes [4](#)  
  settings [13](#)  
next turn [5](#)  
nüMaps Guarantee [1](#)  
nüMaps Lifetime [1](#)

## O

off-road navigation [4](#)  
on-screen buttons [2](#)

## P

pairing [9](#)  
  deleting paired headset [9](#)  
  disconnecting [9](#)  
  phone [9, 15](#)  
parking [3](#)  
  last spot [3](#)  
phone  
  disconnecting [9](#)  
  pairing [9, 15](#)  
phone book [9](#)  
phone calls [9](#)  
  answering [9](#)  
  call waiting [9](#)  
  dialing [9](#)  
  muting [9](#)  
  voice dial [9](#)  
POI. [4](#) *See also* point of interest (POI)  
POI Loader [4](#)  
points of interest (POI Loader) [4](#)  
points of interest (POI)  
  custom [4](#)  
  extras [4](#)  
  POI Loader [4](#)  
power cables [14](#)  
  changing the fuse [14](#)  
  vehicle [1](#)  
power key [1](#)  
product registration [1](#)  
product support [10](#)  
proximity points alerts, settings [13](#)

## Q

Quick Search [2](#)

## R

recently found locations [3](#)  
registering the device [1](#)

- removing mount **14**
- renaming trips **12**
- reports, mileage **11**
- resetting
  - device **1**
  - trip data **6**
- restoring settings **13**
- road conditions, weather **11**
- routes
  - calculating **4**
  - myTrends **6**
  - preferences **13**
  - previewing **4**
  - starting **4**
  - stopping **5**
  - suggested **6**
  - viewing on the map **5**

**S**

- safety cameras, database **7**
- satellite signals
  - acquiring **1**
  - viewing **2**
- saved locations **4, 12**
  - categories **4**
  - deleting **4**
  - editing **3**
- saving, current location **3**
- screen, brightness **2**
- screenshots **13**
- search bar **2**
- settings **13**
- shortcuts
  - adding **4**
  - deleting **4**
- simulated locations **4**
- sleep mode **1**
- Smartphone Link **10**
  - connecting **10**
  - disabling calls **10**
  - Garmin Live Services **10**
- software
  - updating **1**
  - version **13**
- speech recognition **8**
- stops, adding **5**
- subscriptions
  - Garmin Live Services **10**
  - nüMaps Lifetime **1**
  - traffic **1**
- suction cup **14**

**T**

- theft, avoiding **14**
- time settings **2, 13**
- traffic **7, 8, 13**
  - activating a subscription **8**
  - adding subscriptions **8**
  - alternate route **8**
  - cameras **8**
  - incidents **8**
  - lifetime subscriptions **1**
  - map **7**
  - receiver **7**
  - searching for delays **8**
  - trafficTrends **8**
- traffic cameras **8**
  - saving **8**
  - viewing **8**
- trafficTrends **8**
  - disabling **8**
- travel history **13**
- trip computer **6**
  - resetting information **6**
- trip data **5**
  - resetting **6**
- trip information, viewing **6**
- trip log, viewing **6**
- trip planner **11, 12**
  - editing a trip **12**

- troubleshooting **14, 15**
- turn list **5**

## U

- unit ID **13**
- up ahead
  - customizing **5**
  - finding services **5**
- up ahead services **5**
- USB, disconnecting **12**

## V

- vehicle power cable **1**
- vehicle profile **11**
- voice command **8, 9**
  - activating **8**
  - navigating with **9**
  - tips for using **8**
  - wakeup phrase **8**
- volume, adjusting **2**

## W

- weather **11**
  - radar **11**
  - road conditions **11**
- Where Am I? **3, 6**

# www.garmin.com/support



913-397-8200  
1-800-800-1020



0808 238 0000  
+44 870 850 1242



1-866-429-9296



+43 (0) 820 220 230



+32 2 672 52 54



+45 4810 5050



+358 9 6937 9758



+ 331 55 69 33 99



+49 (0)1805-427646-880



+ 39 02 36 699699



0800 - 023 3937  
035 - 539 3727



+ 47 815 69 555



00800 4412 454  
+44 2380 662 915



+ 35 1214 447 460



+ 34 902 007 097



+ 46 7744 52020

## Garmin International, Inc.

1200 East 151st Street  
Olathe, Kansas 66062, USA

## Garmin (Europe) Ltd.

Liberty House, Hounslow Business Park  
Southampton, Hampshire, SO40 9LR UK

## Garmin Corporation

No. 68, Zhangshu 2nd Road, Xizhi Dist.  
New Taipei City, 221, Taiwan (R.O.C.)

